



**Wilson**<sup>®</sup>  
**Electronics, Inc.**

# Adapter List



## Cell Phone Manufacturer

<b>Audiovox (UTStarcom)</b>	<b>Merlin (Novatel)</b>	<b>Sanyo</b>
<b>Cingular &amp; HTC</b>	<b>Motorola</b>	<b>Siemens</b>
<b>Curitel</b>	<b>NEC</b>	<b>Sierra Wireless</b>
<b>Denso</b>	<b>Nokia</b>	<b>Sony / Ericsson</b>
<b>Franklin Wireless</b>	<b>Option</b>	<b>Sprint / Touchpoint</b>
<b>Hitachi</b>	<b>Panasonic</b>	<b>UTStarcom</b>
<b>Kyocera / Qualcomm</b>	<b>Pantech</b>	<b>ZTE</b>
<b>LG (Lucky Goldstar)</b>	<b>Samsung</b>	

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
Audiovox (UTStarcom)	Data Card	5220M	359917	866-294-1660
Audiovox (UTStarcom)	Data Card	PC3220 AirCard	359917	End
Audiovox (UTStarcom)	Data Card	PC3320 AirCard	359912	End
Audiovox (UTStarcom)	Data Card	PC5220 AirCard	359917	End
Audiovox (UTStarcom)	Data Card	PC5740 AirCard	None*	No Port
Audiovox (UTStarcom)	Data Card	UM150	359921	Back Plug
Audiovox (UTStarcom)	Phone	200	359906	Back Plug
Audiovox (UTStarcom)	Phone	219	359906	Back Plug
Audiovox (UTStarcom)	Phone	250	359906	Back Plug
Audiovox (UTStarcom)	Phone	400	359906	Back Plug
Audiovox (UTStarcom)	Phone	888	359906	Back Plug
Audiovox (UTStarcom)	Phone	989	359906	Back Plug
Audiovox (UTStarcom)	Phone	300 Series	359906	Back Plug
Audiovox (UTStarcom)	Phone	BAM 330	356801, 359902	Bottom Plug
Audiovox (UTStarcom)	Phone	CDM 130 Series	359908	Back Plug
Audiovox (UTStarcom)	Phone	CDM 135 Series	359908	Back Plug
Audiovox (UTStarcom)	Phone	CDM 180	359909	Back Plug
Audiovox (UTStarcom)	Phone	CDM 8100	359908	Back Plug
Audiovox (UTStarcom)	Phone	CDM 8410	Not Available	866-294-1660
Audiovox (UTStarcom)	Phone	CDM 8450	Not Available	866-294-1660
Audiovox (UTStarcom)	Phone	CDM 8600 Series	Not Available	866-294-1660
Audiovox (UTStarcom)	Phone	CDM 8900 Series	Not Available	866-294-1660
Audiovox (UTStarcom)	Phone	CDM 8915	359909	Back Plug
Audiovox (UTStarcom)	Phone	CDM 9000 (except 9100 Series)	Discontinued	Back Plug
Audiovox (UTStarcom)	Phone	CDM 9100 Series	356003 / 406004	Bottom Plug / RF Charger
Audiovox (UTStarcom)	Phone	CDM 9500	356003 / 406004	Bottom Plug / RF Charger
Audiovox (UTStarcom)	Phone	CDM 9900	Not Available	866-294-1660
Audiovox (UTStarcom)	Phone	G'ZOne Type-V	359919	Back Plug
Audiovox (UTStarcom)	Phone	PCX 1110	359908	Back Plug
Audiovox (UTStarcom)	Phone	PPC6700/ XV6700	359909	Back Plug
Audiovox (UTStarcom)	Phone	VI600	Not Available	866-294-1660
Cingular	Phone	8125	359909	Back Plug
Cingular & HTC	Data Card	3125	Call TechSupport	866-294-1660
Cingular & HTC	Phone	2100, 2125 (Faraday)	359909	Back Plug

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
Cingular & HTC	Phone	8100,8125 (MDA, K-JAM)	359909	Back Plug
Cingular & HTC	Phone	8525, TyTN, JasJam, Hermes	359909	Back Plug
Cingular & HTC	Phone	APACHE, PPC-6700, XV-6700	359909	866-294-1660
Cingular & HTC	Phone	S620 (Dash, Excalibur)	359909	Back Plug (under mirror)
Cingular & HTC	Phone	S621	359909	Back Plug (under mirror)
Cingular & HTC	Phone	XV6800, PPC6800, P4000, Mogul	359909	Back Plug
Curitel	Phone	Identity	359909	Back Plug
Denso	Phone	1100	359907	Back Plug
Denso	Phone	2200	359907	Back Plug
Franklin Wireless	Data Card	CDU-550 USB air card	None*	No Port
Franklin Wireless	Data Card	CDU-650 USB air card	359923	Side Port
Hitachi	Phone	SH-P300	359908	Back Plug
Kyocera / Qualcomm	Phone	1135	357008	Back Plug
Kyocera / Qualcomm	Phone	2119	357006	Back Plug
Kyocera / Qualcomm	Phone	2135	357006	Back Plug
Kyocera / Qualcomm	Phone	2235	357008	Back Plug
Kyocera / Qualcomm	Phone	2325	357008	Back Plug
Kyocera / Qualcomm	Phone	7135	None*	No Port
Kyocera / Qualcomm	Phone	6035 Smart Phone	357004	Back Plug
Kyocera / Qualcomm	Phone	K612 (Strobe)	None*	No Port
Kyocera / Qualcomm	Phone	KX160	None*	No Usable Port
Kyocera / Qualcomm	Phone	Kx5 (Remix)	Not Available	866-294-1660
Kyocera / Qualcomm	Phone	Q PHONE	357001	Bottom Plug
Kyocera / Qualcomm	Phone	QCP thin 860; 1960; 2760	None*	No Port
Kyocera / Qualcomm	Phone	SE44, SE47 (Slider)	Not Available	866-294-1660
LG (Lucky Goldstar)	Data Card	VL600	359921	Back Plug
LG (Lucky Goldstar)	Phone	245	359919	Back Plug
LG (Lucky Goldstar)	Phone	330	356801	Top Screw
LG (Lucky Goldstar)	Phone	3450	359919	Back Plug
LG (Lucky Goldstar)	Phone	4750	359919	Back Plug
LG (Lucky Goldstar)	Phone	110 Series	359907	Back Plug
LG (Lucky Goldstar)	Phone	510 Series	359907	Back Plug
LG (Lucky Goldstar)	Phone	520 Series	359907	Back Plug
LG (Lucky Goldstar)	Phone	AX245	359919	Back Plug

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
LG (Lucky Goldstar)	Phone	AX355, UX355	359919	Back Plug
LG (Lucky Goldstar)	Phone	AX390	359919	Back Plug
LG (Lucky Goldstar)	Phone	AX4270	359919	Under Battery Cover
LG (Lucky Goldstar)	Phone	AX4650	359919	Back Plug
LG (Lucky Goldstar)	Phone	AX4750	359919	Back Plug
LG (Lucky Goldstar)	Phone	AX490	359919	Back Plug
LG (Lucky Goldstar)	Phone	AX5000	356808	Side Plug
LG (Lucky Goldstar)	Phone	C1300	359919	Back Plug
LG (Lucky Goldstar)	Phone	C1500	359919	Back Plug
LG (Lucky Goldstar)	Phone	C2000	359919	Back Plug
LG (Lucky Goldstar)	Phone	CE500	359919	Back Plug
LG (Lucky Goldstar)	Phone	CG225	359919	Back Plug
LG (Lucky Goldstar)	Phone	CG300	356808	Side Plug
LG (Lucky Goldstar)	Phone	CU320	359919	Back Plug
LG (Lucky Goldstar)	Phone	CU400	359919	Back Port
LG (Lucky Goldstar)	Phone	CU500	359919	Back Plug
LG (Lucky Goldstar)	Phone	CU575 (Trax)	None*	No Port
LG (Lucky Goldstar)	Phone	F7200	359919	Under Battery Cover
LG (Lucky Goldstar)	Phone	F9100	359919	Under Battery Cover
LG (Lucky Goldstar)	Phone	G4015	359919	Back Plug
LG (Lucky Goldstar)	Phone	G4020	359919	Back Plug
LG (Lucky Goldstar)	Phone	L1100	359919	Back Plug
LG (Lucky Goldstar)	Phone	L1150	359919	Back Plug
LG (Lucky Goldstar)	Phone	L1200	359919	Back Plug
LG (Lucky Goldstar)	Phone	L1400	359919	Back Plug
LG (Lucky Goldstar)	Phone	LG CU400	359919	Back Plug
LG (Lucky Goldstar)	Phone	LX350	359919	Back Plug
LG (Lucky Goldstar)	Phone	LX5350	Not Available	866 -294 -1660
LG (Lucky Goldstar)	Phone	LX5450	Not Available	866-294-1660
LG (Lucky Goldstar)	Phone	LX550 (Fusic)	359919	Back Plug
LG (Lucky Goldstar)	Phone	PM225	356808	Side Plug
LG (Lucky Goldstar)	Phone	PM325	None*	No Port
LG (Lucky Goldstar)	Phone	Rumor	359919	Back Plug
LG (Lucky Goldstar)	Phone	Scoop	359919	Back Plug

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
LG (Lucky Goldstar)	Phone	UX210	359919	Back Plug
LG (Lucky Goldstar)	Phone	UX390	359919	Back Plug
LG (Lucky Goldstar)	Phone	UX4750	359919	Back Plug
LG (Lucky Goldstar)	Phone	UX5000	356808	Side Plug
LG (Lucky Goldstar)	Phone	V111	359907	Back Plug
LG (Lucky Goldstar)	Phone	VI125	Not Available	866-294-1660
LG (Lucky Goldstar)	Phone	VI5225	Not Available	866-294-1660
LG (Lucky Goldstar)	Phone	VX1	359907	Back Plug
LG (Lucky Goldstar)	Phone	VX10	359907	Back Plug
LG (Lucky Goldstar)	Phone	VX3280	359919	Back Plug
LG (Lucky Goldstar)	Phone	VX3300	359919	Under Battery Cover
LG (Lucky Goldstar)	Phone	VX3400	359919	Back Plug
LG (Lucky Goldstar)	Phone	VX4600	359909	Back Plug
LG (Lucky Goldstar)	Phone	VX4650	359919	Back Plug
LG (Lucky Goldstar)	Phone	VX4700	359919	Back Plug
LG (Lucky Goldstar)	Phone	VX5200	356808	Side Plug
LG (Lucky Goldstar)	Phone	VX5300	359919	Back Plug
LG (Lucky Goldstar)	Phone	VX5400	None*	No Port
LG (Lucky Goldstar)	Phone	VX565 (Muziq)	359921	Back Plug
LG (Lucky Goldstar)	Phone	VX8000	359909	Back Plug
LG (Lucky Goldstar)	Phone	VX8300	359919	Back Plug
LG (Lucky Goldstar)	Phone	VX8500 (Chocolate)	359919	Back Plug
LG (Lucky Goldstar)	Phone	VX8550 (Chocolate)	None*	No Port
LG (Lucky Goldstar)	Phone	VX8600	359921	Back Plug
LG (Lucky Goldstar)	Phone	VX8700	None*	No Port
LG (Lucky Goldstar)	Phone	VX8800 (Venus)	None*	No Port
LG (Lucky Goldstar)	Phone	VX9100 (enV2)	359919	Back Plug
LG (Lucky Goldstar)	Phone	VX9400	359919	Back Plug
LG (Lucky Goldstar)	Phone	VX9700 (Dare)	359919	Under Battery Cover
LG (Lucky Goldstar)	Phone	VX9800	359909	Back Plug
LG (Lucky Goldstar)	Phone	VX9900 (enV)	359919	Back Plug
LG (Lucky Goldstar)	Phone	VX10000 (Voyager)	None*	No Port
Merlin (Novatel)	Data Card	C201	None*	No Port
Merlin (Novatel)	Data Card	EX720	359918	Side Port

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
Merlin (Novatel)	Data Card	G301	359912	Side Plug
Merlin (Novatel)	Data Card	S620	359918	Side
Merlin (Novatel)	Data Card	S720	359918	Side Port
Merlin (Novatel)	Data Card	U630	359918	Side
Merlin (Novatel)	Data Card	U720, Ovation U720	359909	Back Plug
Merlin (Novatel)	Data Card	U727	359927	Side Port
Merlin (Novatel)	Data Card	U730	359918	Side
Merlin (Novatel)	Data Card	USB720	359909	Top Plug
Merlin (Novatel)	Data Card	USB760	359927	Side Plug
Merlin (Novatel)	Data Card	V620	359918	Side
Merlin (Novatel)	Data Card	V640	359918	Top Plug
Merlin (Novatel)	Data Card	V740	359918	Side Plug
Merlin (Novatel)	Data Card	XU870	359918	Side Plug
Motorola	Phone	C139	None*	No Usable Port
Motorola	Phone	C155, C290	359909	Back Plug
Motorola	Phone	C331, C332, C333, C341 C343, C353	Call Tech Support	866-294-1660
Motorola	Phone	E815/ E816	Not Available	866-294-1660
Motorola	Phone	ic502	None*	No Port
Motorola	Phone	KRZR K1m	None*	No Usable Port
Motorola	Phone	L2	None*	No Usable Port
Motorola	Phone	L6	None*	No Usable Port
Motorola	Phone	Microtac 650	352009	Top Replacement Antenna
Motorola	Phone	Microtac Lite XL	352009	Top Replacement Antenna
Motorola	Phone	MPX 200	None*	No Port
Motorola	Phone	MPX 220	352016	Back Plug
Motorola	Phone	P8000Series (8090; 8097; 8160; 8167; 8767)	402005	RF Charger
Motorola	Phone	Profile 300 Series	352009	Top Replacement Antenna
Motorola	Phone	Q	None*	No Port
Motorola	Phone	Razr2 V9m	None*	No Usable Port
Motorola	Phone	RIZR Z3	Not Availalable	866-294-1660
Motorola	Phone	SC3160	None*	No Port
Motorola	Phone	SLVR L7	352017	Back Plug
Motorola	Phone	StarTac Series	402005	RF Charger
Motorola	Phone	T2000 Series	352006	Back Plug with Top Replacement

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
Motorola	Phone	T300P	Call Tech Support	866-294-1660
Motorola	Phone	T7000 Series	402005	RF Charger
Motorola	Phone	T721, T722	359909	Back Plug
Motorola	Phone	T731	359909	Back Plug
Motorola	Phone	T8000 Series (8090, 8097, 8160, 8167, 8767)	402005	RF Charger
Motorola	Phone	Ultima Series	359909	Back Plug
Motorola	Phone	V170, V171, V173	359909	Back Plug
Motorola	Phone	V180,V186,V188,V190	None*	No Usable Port
Motorola	Phone	V2000 Series	352006	Back Plug with Top Replacement
Motorola	Phone	V220	None*	No Usable Port
Motorola	Phone	V260	359909	Back Plug
Motorola	Phone	V262	359909	Back Plug
Motorola	Phone	V265	359909	Back Plug
Motorola	Phone	V266	359909	Back Plug
Motorola	Phone	V276	359909	Back Plug
Motorola	Phone	V3 Maxx (ve)	352015	Back Plug
Motorola	Phone	V3 RAZR Series (except V3a, V3m, V3x, V3xx)	352015	Back Plug
Motorola	Phone	V323	359909	Under Battery Cover
Motorola	Phone	V325	359909	Under Battery Cover
Motorola	Phone	V330	359909	Back Plug
Motorola	Phone	V360	None*	No Port
Motorola	Phone	V3620, V3682	402005	RF Charger
Motorola	Phone	V3c	352015	Back Plug
Motorola	Phone	V3i	352015	Back Plug
Motorola	Phone	V3m and V3x (Do not use due to weak port)	None*	866-294-1660
Motorola	Phone	V3r	352015	Back Plug
Motorola	Phone	V3xx Razr (Do not use due to weak port)	None*	Back Plug
Motorola	Phone	V400	359909	Back Plug
Motorola	Phone	V65p	Not Available	866-294-1660
Motorola	Phone	V66	352012	Back Plug
Motorola	Phone	V710	359909	Back Plug
Motorola	Phone	V80	None*	No Port
Motorola	Phone	V8160, V8162	402005	RF Charger
Motorola	Phone	W315	352018	Under Battery Cover

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
Motorola	Phone	W385	*Call Tech Support	866-294-1660
Motorola	Phone	W755	352019	Back Plug
Motorola	Phone	X507	None*	No Port
NEC	Phone	525	359002	Side Plug
Nextel/SouthernLINC/Mike	Phone	i2000 plus	354001	Ring
Nextel/SouthernLINC/Mike	Phone	i285	None*	No Port
Nextel/SouthernLINC/Mike	Phone	i30; i35	354006	Back Plug
Nextel/SouthernLINC/Mike	Phone	i370 (except i370R)	354001	Ring
Nextel/SouthernLINC/Mike	Phone	i390	354001	Ring
Nextel/SouthernLINC/Mike	Phone	i50; i55; i58	354004	Back Replacement
Nextel/SouthernLINC/Mike	Phone	i500; i550 plus	354001	Ring
Nextel/SouthernLINC/Mike	Phone	i60	354005	Back Plug
Nextel/SouthernLINC/Mike	Phone	i600	354001	Ring
Nextel/SouthernLINC/Mike	Phone	i605	Not Available	866-294-1660
Nextel/SouthernLINC/Mike	Phone	i670	None*	No Port
Nextel/SouthernLINC/Mike	Phone	i700 plus	354001	Ring
Nextel/SouthernLINC/Mike	Phone	i800 Series	None*	No Port
Nextel/SouthernLINC/Mike	Phone	i85; i88	354004	Back Replacement
Nextel/SouthernLINC/Mike	Phone	i90	354005	Back Plug
Nextel/SouthernLINC/Mike	Phone	i95	354005	Back Plug
Nextel/SouthernLINC/Mike	Phone	ic502	None*	No Port
Nokia	Phone	1100	None*	No port
Nokia	Phone	1221	None*	No Port
Nokia	Phone	1260	None*	No Port
Nokia	Phone	2260	None*	No Port
Nokia	Phone	2610	None*	No Port
Nokia	Phone	3220	None*	No Port
Nokia	Phone	3285	359907	Back Plug
Nokia	Phone	3560	None*	No Port
Nokia	Phone	3570	None*	No Port
Nokia	Phone	3590	None*	No Port
Nokia	Phone	3595	None*	No Port
Nokia	Phone	3600	None*	No Port
Nokia	Phone	3620	None*	No Port

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
Nokia	Phone	3650	None*	No Port
Nokia	Phone	5100	No Port	Back Plug
Nokia	Phone	6010	None*	No Port
Nokia	Phone	6085	None*	No Port
Nokia	Phone	6086	None*	No Port
Nokia	Phone	6100	No Port	Back Plug
Nokia	Phone	6126	None*	No Port
Nokia	Phone	6131	None*	No Port
Nokia	Phone	6133	None*	No Port
Nokia	Phone	6800	None*	No Port
Nokia	Phone	7210	None*	No Port
Nokia	Phone	8265	353007	Back Plug
Nokia	Phone	8270	None*	No Port
Nokia	Phone	8290	None*	No Port
Nokia	Phone	8390	None*	No Port
Nokia	Phone	8890	None*	No Port
Nokia	Phone	2125i, 2126i, 2128i	None*	No Port
Nokia	Phone	3120 (B)	None*	No Port
Nokia	Phone	3300 Series (3360, 3390, 3395)	None*	No Port
Nokia	Phone	3516i	None*	No Port
Nokia	Phone	3585 Series	None*	No Port
Nokia	Phone	3586i	None*	No Port
Nokia	Phone	3588i	None*	No Port
Nokia	Phone	3589i	None*	No Port
Nokia	Phone	6015i, 6016i, 6019i	None*	No Port
Nokia	Phone	6215i	359919	Back Plug
Nokia	Phone	6255i, 6256i	None*	No Usable Port
Nokia	Phone	6300 Series(Except 6305i, 6315i)	359907	Back Plug
Nokia	Phone	6305i	359919	Back Plug
Nokia	Phone	6315i	359919	Back Plug
Nokia	Phone	6590 series	None*	No Port
Nokia	Phone	6610 (i)	None*	No Port
Nokia	Phone	N75	None*	No Port
Nokia	Phone	S621	359909	Back Plug (under mirror)

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
Novatel	Data Card	C777	359936	866-294-1660
Novatel	Data Card	PC770	359936	866-294-1660
Novatel	Data Card	USB1000	359936	866-294-1660
Option	Data Card	GT-Max	359917	Side Plug
Option	Data Card	GT-Max(with wi-fi)	None*	866-294-1660
Panasonic	Phone	GU87	357204	Back Plug
Pantech	Data Card	PX-500	359919	Side Port
Pantech	Data Card	UM W190	359935	866-294-1660
Pantech	Data Card	UM175	359927	Side Port
Pantech	Data Card	UML290	359921	Back Plug
Pantech	Phone	CD3	359909	Back Plug
Pantech	Phone	CDM-180	359909	Back Plug
Pantech	Phone	PG C300	359919	Back Plug
Pantech	Phone	PN205	359919	Back Plug
Pantech	Phone	PN210	359919	Back Plug
Pantech	Phone	PN-212	359909	Back Plug
Pantech	Phone	PN-215	359909	Back Plug
Pantech	Phone	PN218	359909	Back Plug
Pantech	Phone	PN-300	359909	Back Plug
Samsung	Data Card	A870	None*	No Port
Samsung	Data Card	P777	Pending	866-294-1660
Samsung	Phone	210	None*	No Port
Samsung	Phone	411	358001	Bottom Plug
Samsung	Phone	811	None*	No Port
Samsung	Phone	1000	None*	No Port
Samsung	Phone	2000	None*	No Port
Samsung	Phone	2010	None*	No Port
Samsung	Phone	A540	359909	Back Plug
Samsung	Phone	A560	None*	No Port
Samsung	Phone	A570	359909	Back Plug
Samsung	Phone	A580	None*	No Port
Samsung	Phone	A600	359909	Back Plug
Samsung	Phone	A640	None*	No Port
Samsung	Phone	A645	None*	No Port

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
Samsung	Phone	A707 (Sync)	None*	No Usable Port
Samsung	Phone	A717	359921	Under Back Plate
Samsung	Phone	A727	359921	Back Plug
Samsung	Phone	A790	359909	Back Plug
Samsung	Phone	A795	359909	866-294-1660
Samsung	Phone	A840	None*	No Port
Samsung	Phone	A850	None*	No Port
Samsung	Phone	A880	None*	866-294-1660
Samsung	Phone	A900	359921	Under battery cover
Samsung	Phone	A920	None*	No Port
Samsung	Phone	A930	None*	No Port
Samsung	Phone	A950	None*	866-294-1660
Samsung	Phone	A970	359909	Back Plug
Samsung	Phone	C207	None*	No Port
Samsung	Phone	C417	Weak Port	N/A
Samsung	Phone	D347, D357, D407	None*	No Port
Samsung	Phone	D807	359921	Back Plug
Samsung	Phone	E316, E317	None*	No Port
Samsung	Phone	E335	None*	No Port
Samsung	Phone	E715	358006	Back Plug
Samsung	Phone	FlipShot SCH-U900	None*	No Port
Samsung	Phone	i607 BlackJack	359921	Under Back Plate
Samsung	Phone	i730	359909	Back Plug
Samsung	Phone	MA700	359909	866-294-1660
Samsung	Phone	N370	359909	Back Plug
Samsung	Phone	P107	358006	Back Plug
Samsung	Phone	P207	359919	Back Plug
Samsung	Phone	R510 Wafer	359921	Back Plug
Samsung	Phone	T609	None*	No Port
Samsung	Phone	T629	None*	No Port
Samsung	Phone	T729 (Blast)	None*	No Port
Samsung	Phone	U340 (Snap)	None*	No Port
Samsung	Phone	U410	None*	No Port
Samsung	Phone	U420	359919	Under Battery Cover

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
Samsung	Phone	U540	None*	No Port
Samsung	Phone	U700 (Gleam)	None*	No Port
Samsung	Phone	X495, X497	None*	No Port
Samsung	Phone	X506	None*	No Port
Samsung	Phone	X507	None*	No Port
Samsung	Phone	SGHD807	359921	Back Plug
Sanyo	Phone	4700	359908	Back Plug
Sanyo	Phone	4900	356501	Back Plug
Sanyo	Phone	4920	Not Available	866-294-1660
Sanyo	Phone	5300	356504	Back Plug
Sanyo	Phone	6200	356502	Back Plug
Sanyo	Phone	6400	356502	Back Plug
Sanyo	Phone	4500 (Except VM4500 / SCP5500)	359908	Back Plug
Sanyo	Phone	5400 (RL2500)	356506	Back Plug
Sanyo	Phone	7200 (RL2000)	Call Tech Support	866-294-1660
Sanyo	Phone	MM7400	Not Available	866-294-1660
Sanyo	Phone	MM7500	None*	866-294-1660
Sanyo	Phone	VI2300	None*	866-294-1660
Siemens	Phone	C61	None*	No Port
Siemens	Phone	S46	358602	Back Plug
Siemens	Phone	S66	358604	Back Plug
Siemens	Phone	SL56	None*	No Port
Sierra Wireless	Data Card	885	359927	Side Port
Sierra Wireless	Data Card	597u	359927	Side Port
Sierra Wireless	Data Card	727 usb	359927	Side Port
Sierra Wireless	Data Card	AirCard 300	359912	End
Sierra Wireless	Data Card	AirCard 309	359936	866-294-1660
Sierra Wireless	Data Card	Aircard 3300	359917	866-294-1660
Sierra Wireless	Data Card	AirCard 350	359912	End
Sierra Wireless	Data Card	Aircard 5220M	359917	866-294-1660
Sierra Wireless	Data Card	AirCard 550	359912	End
Sierra Wireless	Data Card	AirCard 555	359912	End
Sierra Wireless	Data Card	AirCard 580	359917	End
Sierra Wireless	Data Card	AirCard 595	359923	Top Plug

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
Sierra Wireless	Data Card	AirCard 595u	359912	Side Port
Sierra Wireless	Data Card	AirCard 597e	359912	End Plug
Sierra Wireless	Data Card	AirCard 750	359912	End
Sierra Wireless	Data Card	AirCard 775	359912	End
Sierra Wireless	Data Card	AirCard 850	359912	End
Sierra Wireless	Data Card	AirCard 860	359912	Side Port
Sierra Wireless	Data Card	AirCard 875	359912	End Plug
Sierra Wireless	Data Card	AirCard 881	359912	End Plug
Sierra Wireless	Data Card	AirCard 881u	359912	Side Port
Sierra Wireless	Data Card	AirCard AC500	359936	866-294-1660
Sierra Wireless	Data Card	AirCard AC504	359936	866-294-1660
Sierra Wireless	Data Card	AirCard U302	359936	866-294-1660
Sierra Wireless	Data Card	AirCard U305	359936	866-294-1660
Sierra Wireless	Data Card	AirCard U308	359936	866-294-1660
Sierra Wireless	Data Card	AirCard USB301	359936	866-294-1660
Sierra Wireless	Data Card	AirCard USB307	359936	866-294-1660
Sierra Wireless	Data Card	AirCard USB309	359936	866-294-1660
Sierra Wireless	Data Card	Compass	359927	Side Port
Sierra Wireless	Data Card	PC3220 AirCard	359917	End
Sierra Wireless	Data Card	PC3320 AirCard	359912	End
Sierra Wireless	Data Card	PC5220 AirCard	359917	End
Sierra Wireless	Data Card	PC5740 AirCard	None*	No Port
Sierra Wireless	Data Card	PC5750 AirCard	359919	Side Port
Sierra Wireless	Phone	X506	None*	No Port
Sony / Ericsson	Data Card	GC89 data air card	355015	Antenna Replacement
Sony / Ericsson	Phone	R280 LX	355005	Top Replacement Antenna
Sony / Ericsson	Phone	R289 LX	355005	Top Replacement Antenna
Sony / Ericsson	Phone	R300 LX	None*	No Port
Sony / Ericsson	Phone	R320 S	359906	Back Plug
Sony / Ericsson	Phone	R380 Series	359906	Back Plug
Sony / Ericsson	Phone	R520 Series	359906	Back Plug
Sony / Ericsson	Phone	S500	None*	No Port
Sony / Ericsson	Phone	S710a	355013	Back Plug
Sony / Ericsson	Phone	T206	355008	Back Plug

<b>Manufacturer</b>	<b>Type</b>	<b>Model Number</b>	<b>Product #</b>	<b>Port Position</b>
Sony / Ericsson	Phone	T226, T237, T290a	None*	No Port
Sony / Ericsson	Phone	T28 Series	359906	Back Plug
Sony / Ericsson	Phone	T300	None*	No Port
Sony / Ericsson	Phone	T306	None*	No Port
Sony / Ericsson	Phone	T610	355010	Back Plug
Sony / Ericsson	Phone	T616	355010	Back Plug
Sony / Ericsson	Phone	T62u	355009	Back Plug
Sony / Ericsson	Phone	T637	355010	Back Plug
Sony / Ericsson	Phone	W580	None*	No Port
Sony / Ericsson	Phone	Z500 (a)	355012	Back Plug
Sony / Ericsson	Phone	Z520(a), Z525	None*	No Usable Port
Sprint / Touchpoint	Data Card	CF2031 data air card	359905	Antenna Replacement
UTStarcom	Data Card	UM150	359921	Bottom Plug
UTStarcom	Phone	8630	None*	No Port
UTStarcom	Phone	Coupe	None*	No Port
ZTE	Data Card	MF633+	359936	866-294-1660
ZTE	Data Card	MF633BP+	359936	866-294-1660
ZTE	Data Card	MF668+	359936	866-294-1660